


1




Ø 3/8"

↓ 1"


Drill a hole in the base material using a 3/8" diameter masonry bit. Drill the hole to 1" depth. Blow the hole clean using compressed air.

2




Insert Drop-In anchor into hole. Tap with hammer until flush against surface.

3




Using the Drop-In setting tool, drive expander plug towards the bottom of the anchor until shoulder of setting tool makes contact with the top of the anchor.

4




Place rack and screw anchor into wall.

1




Drill a hole in the base material using a 1/4" diameter masonry bit.

2




Blow the hole clean using compressed air.

3




Tap in concrete anchor.

1



Drill small pilot holes into wood studs.
Drywall alone is not sufficiently strong to support loaded rack.

2



Place rack and use provided wood screws to secure to wall.