



DERO
A PLAYCORE Company



Tool Kit

The Dero Tool Kit includes all the necessary tools to perform most routine maintenance and adjustments on most bikes. All the tools are securely fastened with stainless steel cables and tamper-proof fasteners.

Patents: D717,214 – 9,095,973B2 – 9,505,124B2


©2023

Tool Kit



INCLUDED TOOLS

- Philips and flat head screwdrivers
- 2.5, 3, 4, 5, 6, 8mm Allen wrenches
- Headset wrench
- Pedal wrench
- 8, 9, 10, 11mm box wrenches
- Tire levers (2)
- T25 Torx Wrench

 Tamper-resistant fasteners included!

FINISH OPTIONS

Galvanized



Stainless



Powder Coat






DERO
A PLAYCORE Company

Tool Kit

Submittal Sheet



Tools Included:

1. Philips and flat head screwdrivers
2. 2.5, 3, 4, 5, 6, 8mm Allen wrenches
3. Headset wrench
4. Pedal wrench
5. 8, 9, 10, 11mm box wrenches
6. Tire levers
7. T25 Torx Wrench

MATERIALS

Main body: 6.308 x .154" tube, 3/16" plate
Top cap: 3/16" plate
Tool tethers: 5/32" stainless steel cable

FINISHES

☐

Galvanized

An after fabrication hot dipped galvanized finish is our standard option.

☐

Powder Coat

Our powder coat finish assures a high level of adhesion and durability by following these steps:

1. Sandblast
2. Epoxy primer electrostatically applied
3. Final thick TGIC polyester powder coat

☐

Stainless

Stainless Steel: 304 grade stainless steel material finished in either a high polished shine or a satin finish.


MOUNT OPTIONS


☐

Wall mount


Wall mount has a 6" dia. x 3/16" base plate that is installed onto a wall with 2 anchors.

Wall Setback: The Tool Kit should be mounted on a wall at least 54" from the ground to the center of the Tool Kit. The Tool Kit should be 36" from an adjacent wall.




1


The Tool Kit wall-mount should be installed with the center of the Tool Kit 54" above the ground.

2


There are 4 mounting holes; only 2 need to be used. For installations into a vertical stud, use the 2 vertically oriented holes. The horizontally oriented holes can be used for other types of installation. 3/8" wedge anchors, lag bolts, or other fasteners may be used.

3


Once the base is installed, place the tool cables in the slots, and fasten the cap with the provided 3/8" tamper-resistant bolt.