






Type Rider® Racks

Bike parking makes a statement. The line of Type Rider® racks offers customers the chance to have fun with letters and symbols. These laser cut, hand-welded bike racks can be arranged to spell out a word, brand name, and even hashtag. Each letter parks two bikes.

Type Rider® Racks








FINISH OPTIONS

Galvanized **Powder Coat** Light Gray RAL 7042 White Black Deep Red Yellow RAL 3003 RAL 1023 CNH Bright Iron Gray Hunter Green Orange RAL 2004 Beige RAL 1001 Yellow RAL 7011 Sky Blue RAL 5015 Sepia Brown RAL 8014 Light Green RAL 6018 Green RAL 6016 Blue RAL 5005 Silver RAL 9007 Wine Red Dark Purple Flat Black Bronze






CAPACITY	2 Bikes
MATERIALS	Laser cut 5/8" steel plate hand-welded to 5/8" steel base
FINISHES	Galvanized An after fabrication hot dipped galvanized finish is our standard option. Pre-fabrication galvanizing is standard on panel components.
	Powder Coat Our powder coat finish assures a high level of adhesion and durability by following these steps: 1. Sandblast 2. Epoxy primer electrostatically applied 3. Final thick TGIC polyester powder coat

MOUNT OPTIONS

Surface only

Each Type Rider® Rack has a 5/8" steel base plate with four anchor holes for 3/8" bolts. Tamper-resistant fasteners available upon request.








TOOLS NEEDED


Tape Measure Marker or Pencil Masonry Drill Bit Drill (Hammer drill recommended) Hammer Wrench 9/16" Level

RECOMMENDED BASE MATERIAL


Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.




Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.



Drill 3/8" diameter holes 3" deep into surface. Make sure the holes are at least 3" away from any cracks in the base material.



Place rack (and washers to level rack if necessary) over holes.



Thread nuts onto anchors, leaving approximately 1/4" of the anchor protruding, and tap into surface. Tighten nuts down to secure rack.